

Thank you for purchasing your Kampa shelter. Please read these instructions carefully before attempting to set up your shelter and retain for future reference. If used properly, your shelter should give you years of trouble free use. We recommend that your shelter is insured against accidental and storm damage as this is not covered by the warranty. Shelters contain a high proportion of synthetic materials and under certain conditions will be affected by condensation inside the shelter. This should not be confused with leaking and condensation can be improved by ensuring adequate ventilation.

We recommend a trial run before using your shelter for the first time. This will allow you to familiarise yourself with the shelter, its set up and any limitations the shelter may have for your particular use.


Two people are recommended for the set up of this shelter

### Step 1 - Layout the shelter

Select a level, sheltered site for your shelter.  
Remove all the parts from the carry bag.


### Step 2 - Extend the frame

Take the folded frame and place it in the centre of your site. Each person should grasp legs that are diagonally opposite and pull backwards to extend the frame.



Make sure the frame is fully extended.

Slide the lock 'A' on the leg upward until it snaps into place. See diagram



Make sure the joints on the centre roof support poles are straightened and snapped into place.

### Step 3 - Install the roof

Drape the roof over the frame, stretching the corners of the roof over the corners of the frame.



The roof will be taut after you stretch the roof fully over the frame.

Duck under the roof and fasten the velcro straps 'B' attached to the roof around the frame (or if you are tall you can do this after Step 4!)


### Step 4 - Raise the shelter

Pull up on the leg sections until push button snaps into place, locking the legs.

If conditions warrant, drive the stakes through the holes in the feet of the leg poles to secure the shelter.

### Step 5 - Install the guy lines

For maximum security, always install the guy lines provided (C, D). Secure with the pegs provided.



## **RAIN**

We make our shelters as resistant to the weather as possible. Occasionally you may find slight leakage. This is not a fault with the manufacturing process or materials and can normally be rectified by spot treating the seam with seam sealant (see below).

## **SEAMS**

The main seams of this shelter have been factory taped to help prevent leakage. Depending upon your expectations, it may be necessary to treat the remaining seams with a seam sealant. Seam sealant should also be applied to areas where the taping is damaged or has peeled away through wear and tear. It can also be applied to areas where a leak may have developed. Seam sealant is available through your dealer. We recommend Kampa seam sealant.

## **SUITABILITY**

This shelter is designed for use in light to moderate weather. During very strong winds or snowfall we recommend that you take your shelter down. The shelter is designed for occasional use; it is not designed for static use.

## **UV DEGRADATION**

Shelter fabrics can be weakened by prolonged exposure to sunlight. Under normal use your shelter will give long service but use for extended periods in strong sunlight will soon cause deterioration. In those cases it would be wise to use a site as shaded as possible. UV degradation is not covered under the warranty. The warranty does not cover shelters used on permanent sites, displays or for commercial purposes.

## **CONDENSATION**

Shelters contain a high proportion of synthetic materials and under certain conditions will be effected by condensation inside the shelter. **This should not be confused with leaking.** Condensation can be improved by ensuring adequate ventilation. Condensation and its effects are not covered under the warranty.

## **SAFETY**

**DO NOT COOK IN THE SHELTER OR USE NAKED FLAMES.**

## **DISMANTLING**

Reverse the set up procedure. It is not necessary to remove the roof from the frame.

## **CARE**

Tents are best stored opened out. Air fully and ensure it is totally dry before packing away. Store in a well ventilated dry place. A wet/damp tent will develop mildew surprisingly quickly. Dirty tents can be washed using clean water and a soft brush. Do not scrub and never use detergents.

The frame should be protected from damage and should be stored completely dry to prevent corrosion. Damage due to improper use, wind damage or neglect is not covered under the warranty. Have any damage repaired at the first opportunity. Failure in the frame normally occurs through incorrect use.

## **WARRANTY**

We guarantee this product from manufacturing defects for twelve months from date of purchase. The guarantee does not cover slight leakage, condensation, UV degradation, storm/weather damage, improper use, improper set up, permanent use, commercial use, displays or modification. Any complaint should be made to your supplying dealer with the original receipt. Please ensure that your shelter is dry and clean before returning to your dealer for inspection. Your dealer may refuse to handle any product that is returned in an unsuitable condition.

## **SPARE PARTS**

A full range of spare parts can be purchased from your supplying dealer or Kampa.