



Canopy User Guide

Suits: Paloma 4 AIR

Paloma 5 AIR

Paloma 6 AIR

Welcome

Thank you for purchasing your Kampa canopy. Please read these instructions carefully before attempting to set up and retain for future reference. If used properly, your canopy should give you years of trouble free use. We recommend that your canopy is insured against accidental and storm damage as this is not covered by the warranty.



Your tent and canopy are designed for use in light to moderate weather. During strong winds or snowfall we recommend that you take your tent down. The tent is designed for touring use; it is not designed for static or commercial use.

We recommend a trial run before using your tent and canopy for the first time. This will allow you to familiarise yourself with the tent, its set up and any limitations the tent and canopy may have for your particular use.

SET UP

1. Locate the zip at the top of the front canopy and zip the canopy on.
2. Once attached, thread the canopy pole through the pole sleeve and attach it to the ring and pins located on at the base of the strap. Ensure that these are tensioned.
3. Peg the canopy corners taught before pegging the remaining pegging points.
4. Peg the guylines so that the canopy is under tension without distorting the shape, they should run in line with seams.
5. The canopy comes with a separate groundsheet.