



Canopy User Guide

Suits: Bergen 6 AIR Pro

Croyde 6 AIR Pro

Hayling 4 AIR Pro

Hayling 6 AIR Pro

Studland 8 AIR Pro

Welcome

Thank you for purchasing your Kampa canopy. Please read these instructions carefully before attempting to set up and retain for future reference. If used properly, your canopy should give you years of trouble free use. We recommend that your canopy is insured against accidental and storm damage as this is not covered by the warranty.



Your tent and canopy are designed for use in light to moderate weather. During strong winds or snowfall we recommend that you take your tent down. The tent is designed for touring use; it is not designed for static or commercial use.

We recommend a trial run before using your tent and canopy for the first time. This will allow you to familiarise yourself with the tent, its set up and any limitations the tent and canopy may have for your particular use.

SET UP

1. Locate the zip at the top of the front AirPole and zip the canopy on.
2. Peg the canopy corners taught before inflating the canopy, as you would with the tent.
3. Peg the remaining intermediate pegging points.
4. Peg the QuickPitch guying strap so that the canopy is under tension without distorting the shape, they should run in line with seams.
5. The canopy comes with a separate groundsheet. Install the canopy groundsheet by attaching the toggles on the groundsheet, to the corresponding 'O' rings situated around the inside of the canopy.

Storm Tie Down Kit

For extra security the tent is supplied with a Storm Tie Down Kit. Attach each tie down to the side release buckle already sewn to each corner of the tent. The front two can be taken from the tent and attached to the canopy instead.