

### Welcome

Thank you for purchasing your Kampa canopy. Please read these instructions carefully before attempting to set up and retain for future reference. If used properly, your canopy should give you years of trouble free use. We recommend that your canopy is insured against accidental and storm damage as this is not covered by the warranty.



Your tent and canopy are designed for use in light to moderate weather. During strong winds or snowfall we recommend that you take your tent down. The tent is designed for touring use; it is not designed for static or commercial use.

We recommend a trial run before using your tent and canopy for the first time. This will allow you to familiarise yourself with the tent, its set up and any limitations the tent and canopy may have for your particular use.

### SET UP

1. Spread the canopy on the ground and locate the two black pole sleeves on the roof.
2. Thread the canopy poles through the pole sleeves and attach them to the ring and pins located on at the base of the strap. Ensure that these are tensioned.
3. Stand the canopy upright and pull into shape. If necessary use the guy lines to help hold the canopy upright.
4. Position the canopy into the required location with the rear tunnel (open end) towards the tent.
5. Throw the two guy lines, found at the top corners of the rear tunnel, over the tent and peg down ensuring that they are pulled taught from each other.
6. Close the door fully.
7. Peg the canopy corners taught before pegging the remaining pegging points.
8. Check the positioning of the canopy on the tent and, if necessary adjust.
9. Peg the guylines so that the canopy is under tension without distorting the shape, they should run in line with seams.